

ULTRASlimline[®] Tower Fan



Control Panel



ON / OFF: Turns fan ON & OFF



Timing Selection: Time increases with each push of the button.
The sum of the lit LEDs is the total time remaining before shut-off.



Speed Selection: Allows five different speed settings

1

Low

2

Medium Low

3

Medium

4

Medium High

5

High



Oscillating Selection :
This function starts and stops the oscillation of the fan.



Selection of Wind: Allows for three different wind modes.



Normal Wind :
The Normal Wind mode is simply the Low, Medium Low, Medium, Medium High, and High fan speed settings.



Sleeping Wind :
The Sleeping Wind allows you to set a speed and that speed will gradually lower to Low.
The air flows as an evening breeze slowing to a light night breeze.

Low Sleeping Wind : The air flow remains at Low.

Medium Low Sleeping Wind : The air flow begins at medium low for a half an hour and then drops to Low.

Medium Sleeping Wind :
The air flow begins with medium speed for a half hour then drops to medium low speed for a half an hour and finally drops to Low.

Medium High Sleeping Wind :
The air flow begins with medium high speed for a half hour then drops to medium speed for a half an hour, then Medium Low for a half hour and finally drops to Low.

High Sleeping Wind :
The air flow begins with High speed for a half hour then drops to Medium speed for a half hour, then to medium low for a half an hour and finally drops to Low.




Natural Wind :
The Natural Wind mode automatically selects wind speed randomly as you would find outdoors.
The speeds are graphically described on the next page.

ULTRASlimline[®] Tower Fan




Natural Wind Modes


Low Natural Wind




Medium Low Natural Wind




Medium Natural Wind




Medium High Natural Wind



High Natural Wind



Remote Control for Tower Fan



Power Button - Turns fan ON and OFF.



Speed Mode - Changes wind speed from Low to Medium Low to Medium to Medium High to High.



Wind Mode - Changes mode from Normal Wind to Natural Wind to Sleeping Wind.



Timer - Changes the time the fan is on from 1 hr. up to a maximum of 12 hr., in 1 hr. increments.



Oscillation - Turns the fan oscillation ON or OFF.



Use "+" to increase speed or timer setting
Use "-" to decrease speed or timer setting
Push "+" and "-" at the same time, to switch temperature display between celsius and Fahrenheit.