


FIREFLY®

Welcome to the Firefly family! Our top priority is to give you the best experience and value from your purchase. Please carefully read through the manual to enjoy your new Firefly product.

SAFETY AND GENERAL INFORMATION

- For your safety, read the manual and safety instructions before use.
- Children should be supervised to ensure that they do not play with the appliance.
- "X" type supply cord: If the supply cord is damaged, it must be replaced by similar cord with the same current rating.
- Do not pull the power cord excessively when unplugging it. Do not bend or damage the power cord. Avoid touching the power cord, plug or socket with wet hands or wet body parts.
- The product may become slightly warm during charging and this is normal.
- Do not use near flammable and explosive materials or where water and vapor are present.
- Do not drop or cause excessive impact to the product as this may damage your unit or may cause malfunction, shorten its lifespan or may cause overheating and risk of fire.
- During storage, turn off the switch and disconnect the unit from the power supply.
- Contact the manufacturer or a qualified technician if the product fails to function as stated on the packaging or manual.

PRODUCT DETAILS



TECHNICAL SPECIFICATIONS:

Operating Voltage	5V DC
Battery Type	3.7V 2Ah Lithium-Ion Battery
Charging Time	7 Hours
Usage Duration	6 Hours - Side Lamp 4 Hours - Torch
Dimension	130 x 55 x 40 mm


RECHARGEABLE HANDY FLASHLIGHT

FEL562

PRODUCT FEATURES

- Overcharge and overdischarge protection
- Built-in LED lamp
- Push button switch (Torch, Side Lamp, OFF)
- With full charge indicator

CONNECTION DIAGRAM



HOW TO OPERATE THE UNIT

1. Connect the DC power adaptor to the power supply.
2. The charging indicator will turn red when charging and green when fully charged.
3. To use the product, 1st press: LED torch; 2nd press: LED lamp; 3rd press: To turn OFF the product.

USAGE AND MAINTENANCE

- Adjust the lamp according to your preference.
- Do not put the product in unstable, flammable and wet area.
- Avoid exposing the product to heavy fumes or smoke.
- Do not immerse in water or any other liquid . This is a non-water resistant product.
- Do not alter or modify the unit, the supplier will not be responsible for any personal injury because of the item misuse.
- To protect the validity of the warranty, do not use the product for anything other than its intended purpose.

ATTENTION WHEN CLEANING

- Make sure to unplug the unit from the power supply before cleaning.
- Use a soft and damp cloth when cleaning the product. Do not use wet or abrasive material during cleaning.
- Do not use chemicals and detergents to avoid product discoloration.
- Do not attempt to open any part of the product when cleaning.

We would love to hear from you. For comments and suggestions, you can email us at info@fireflyelectric.com

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.