

kyowa

RICE COOKER

MODEL NO.: KW-2006

Voltage: 230Va.c. 60Hz Power: 700 WATTS




INSTRUCTION MANUAL

CONGRATULATIONS

You are now a proud new owner of a KYOWA Rice Cooker model no. KW-2006.

Before using for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for your future reference. If you will pass this Rice Cooker to a third party, please also provide this instruction manual.

PARTS DESCRIPTION



IMPORTANT SAFEGUARDS

When using your Rice Cooker, basic safety precautions should always be followed:

- Always operate your KYOWA Rice Cooker from a power source of the same voltage and frequency rating as indicated on the rating label.
- Connect the Rice Cooker unit only to properly wired wall outlets.
- Place the Rice Cooker on a flat surface and far from the edge of counter top.
- Keep at least 1 inch of space between the Rice Cooker and the wall for proper ventilation.
- Do not operate the Rice Cooker if any part of it including the supply cord has been damaged. Return the appliance to the nearest authorized service facility for repair.
- Do not operate or place any part of your Rice Cooker on or near any hot surface such as a gas or electric burner, hotplate or heated oven.
- Do not use or replace accessories of the Rice Cooker other than the ones originally provided.
- Do not operate Rice Cooker if the inner pot is empty.
- Some parts of the Rice Cooker have been slightly greased and as a result, the cooker might slightly emit smoke when connected for the first time. This however, will cease after you have used the unit for some time.
- Avoid touching hot surfaces of the cooker during use. Use the handle only.
- The heating element surface of the Rice Cooker is subject to residual heat after use, lift using the cover handle or side handles only.
- Switch OFF and unplug the Rice Cooker from outlet when not in use or before cleaning.
- Hold plug when unplugging from socket. Do not unplug by pulling the supply cord.
- Use caution when removing pot from the Rice Cooker after operation.
- To reduce the risk of electric shock, do not immerse or expose the Rice Cooker to rain, moisture or any liquid.
- Do not operate the Rice Cooker if any part of it including the supply cord has been damaged in any manner. Bring the appliance to the nearest authorized service facility for repair.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons with reduced physical sensory or mental capabilities, lack of experience and knowledge, unless they have been given proper supervision concerning use of the appliance by a person responsible for their safety.
- This Kyowa Rice Cooker is intended for normal/domestic household use only and is not suitable for commercial use.

HOW TO USE

- Wash rice grains in a separate container. Do not use the inner pot for washing rice to prevent it from getting deformed or scratched.
- Transfer rice into the inner pot. Always fill in pot with enough rice and water reaching the MIN mark but not exceeding the MAX marking.
- Put enough water into the pot to cover rice. Pour one cup of water for every cup of rice – this however depends on the type of rice used and as well as to personal preference when cooking.
- Place inner pot into the cooker. See to it that the base of the inner pot as well as the surface of the heating plate is dry and clean. Slightly turn the pot from left to right to make sure it properly touches the heating plate.
- Plug in power cord into the rice cooker unit making sure that it is firmly set in place.
- Plug the other end of the power cord into the power supply.
- Warm indicator light shall illuminate.
- Press down switch to turn the unit ON. COOK indicator light shall illuminate to indicate that the unit is working.
- Rice cooker will automatically switch to WARM once the rice is cooked already; WARM indicator lamp will then light up.
- Allow rice to sit for about 15 minutes before serving.
- Unplug power cord from the power supply when not in use or if you are not intending to use the keep warm function of the cooker.



CLEAN AND CARE

- Allow Rice Cooker to cool down completely before cleaning.
- Wash inner pot with warm water and a mild dishwashing soap.
- To remove rice residue in the pot, soak it with warm soapy water overnight then rinse.
- Do not use harsh cleaning agents or abrasive objects (e.g. scrubbing pads or metal brushes) for cleaning.
- Clean outer surfaces of the Rice Cooker with a soft and damp cloth.
- Wipe dry Rice Cooker with a soft and dry cloth then store in a clean and dry place.
- Put back parts and accessories of the Rice Cooker to their proper places before operating again.

SERVICE

- Do not operate your KYOWA Rice Cooker if the rice cooker malfunctions or appears damaged in any manner. Bring the complete product to the place of purchase or to any authorized KYOWA service centers for inspection, repair or replacement.
- Do not disassemble your KYOWA Rice Cooker by yourself. No user serviceable parts inside. Refer all needed repair to an authorized KYOWA service facility ONLY.

kyowa **WARRANTY CARD**

Thank you for choosing Kyowa Appliances! By availing our product, you are entitled to 1 YEAR LIMITED WARRANTY from the date of purchase of the product. However, this product warranty does not cover and/or may be invalidated due to the following reasons.

1. Batteries, bulbs, and glass parts are not covered by the warranty.
2. Customer failed to present warranty card and sales invoice/ official receipt upon request of service.
3. Faulty installation, unauthorized repairs, and/or modification to the product.
4. Product misuse, negligence, accident during transit and/or during use by the customer.
5. Normal wear and tear, natural disasters, fire, pollution, and abnormal power voltage which may cause damage to the product.

Email this copy to **customerservice@kyowa.com.ph**
to request a warranty card number.

PRODUCT NAME & MODEL NO/SERIAL NO: _____

DATE OF PURCHASE: _____ PLACE OF PURCHASE: _____

CUSTOMER NAME: _____

ADDRESS: _____

EMAIL: _____

My signature below acknowledges that I have read, fully understood and
accepted this limited warranty agreement.

SIGNATURE: _____ DATE: _____

WARRANTY CARD NO: _____

(to be provided by Kyowa representative)

KYOWA SERVICE CENTER (MAIN)

METRO MANILA

TRONIX QUEZON CITY (MAIN) #777 N.S. AMORANTO ST, COR. STO. DOMINGO AVE, Q.C.

TEL: (02) 8743-9094 / (02) 8749-8477 MOBILE: 0917-523-1489 / 0928-504-7715

CONTACT PERSON: MS. CHERRY BARTOLOME / MICHELLE BEA

TRONIX MANILA #1793 CONCEPCION AGUILA ST, NEAR J.P. LAUREL ST, SAN MIGUEL, MANILA (NEAR MALACANANG / ST. JUDE)

TEL: (02) 8734-4088 MOBILE: 0922-790-9555 / 0997-602-2545 CONTACT PERSON: MS. ROZELA RABANAL

TRONIX STA. CRUZ/BINONDO #910 LUZON ST. (BET. MASANGKAY & BENAVIDEZ ST.) STA. CRUZ, MANILA TEL:(02) 8542-8345/(02) 5310-3553 MOBILE: 0922-238-9971/0997-602-2543 CONTACT PERSON: MS. ROSE BELAMIA

TRONIX SAN JUAN #135 N.DOMINGO ST, CORNER PINAGLABANAN, BRGY. BALONG BATO, SAN JUAN CITY TEL: (02)7949-3608/ (02)7984-6395/8721-9147 MOBILE: 0922-921-8653 CONTACT PERSON: MS. NORA CRESENCIO

TRONIX ALABANG TOWN CENTER LA-7 SERVICE TOWN, ALABANG TOWN CENTER, MUNTINLUPA CITY TEL: (02) 8807-3546 MOBILE: 0922-758-4917 / 0917-589-9059 CONTACT PERSON: MS. CHARMIE MURILLO

TRONIX PARAÑAQUE CMSR BLDG., #88 PRESIDENT AVENUE., BF HOMES, SUCAAT, PARANAQUE CITY TEL: (02) 8828-2915 MOBILE: 0997-602-2882/0932-406-0806 CONTACT PERSON: MS. CATHERINE CORNEJO

TRONIX MARIKINA #37 BAYAN-BAYANAN AVENUE, CONCEPCION MARIKINA TEL: (02) 7621-4663 MOBILE: 0997-602-2881 / 0942-094-0088 CONTACT PERSON: MS. MARLENE NAPIERE

VALENZUELA CITY

PRECISION ELECTRONICS SERVICES CENTER #95 STALL #2 MAC ARTHUR HIGHWAY, MARULAS, TEL: (02) 7239-2261 MOBILE: 0916-319-7863 CONTACT PERSON: MS. SHIRLEY

BULACAN

TECH-MASTERS ELECTRONICS REPAIR SERVICES #120 UNIT 3 ACPT BUILDING LOCATED AT CIUDAD DE VICTORIA, BY-PASS ROAD BRGY. IGULOT, BOCAUE BULACAN TEL: (02) 044- 6179977 / (02) 044-8140122 MOBILE: 0945-1435224 / 0936-2883858 CONTACT PERSON: MS. CATHERINE GRACE LILLES

CAVITE

NBJ ELECTRONICS REPAIR CENTER BRGY. STA CLARA CONGRESSIONAL RD. H2 DASMARINAS CAVITE MOBILE 0916-553-9782 CONTACT PERSON: MR. NELSON JAVIER

BATANGAS

NBJ ELECTRONICS REPAIR CENTER 270 PUROK1, BRGY. SAN VICETE, STO TOMAS, BATANGAS MOBILE: 0906-046-2433 / 0912-820-0528 / 0917-853-3687 CONTACT PERSON: MR. ALMAR MABANSAG

OLONGAPO

OBP APPLIANCE SERVICE CENTER #50 GALAGGHER ST., EAST TAPINAC OLONGAPO CITY TEL: (047) 232-3234 MOBILE: 0999-972-0250/0915-687-016 CONTACT PERSON: ORLINO PULIDO JR

TARLAC

MAC AIRE COOLING INDUSTRIES CORP. PANGANIBAN ST., STO CRISTO, TARLAC CITY MOBILE: 0919-080-6741/ 0917-514-8590/ 0919-080-6740 CONTACT PERSON: ANGELA PANGAN

CABANATUAN

ACTRON ELECTRONICS NO. 3 MASONIC BLDG., DEL PILAR ST., BRGY. SANGITAN,
CABANATUAN CITY, NUEVA ECIIJA

MOBILE: 0917-559-6049 / 0917-687-0167 CONTACT PERSON: MR. ALBERT TIAMZON/MS. BIBIAN

ISABELA

MRG INTERCOOL REFRIGERATION & AIRCONDITIONING SERVICES

IPIL ST., DISTRICT-1 CAUAYAN CITY ISABELA

MOBILE: 0953-009-5363/0905-582-2425 CONTACT PERSON: MR. MIGUEL MARIANO/MS. KRISTINE QUILALA

BAGUIO

JCF ELECTRONICS REPAIR SHOP 322-A LOWER MAGSAYSAY, BAGUIO CITY

TEL: (074) 422-2862 / (074) 423-2044 MOBILE: 0908-135-1100 / 0917-850-1977

CONTACT PERSON: MR. ABEL OKELLY

TRINIDAD

JCF ELECTRONICS REPAIR SHOP JB 26 KM4, Pico La Trinidad (Near BPI)-(BRANCH)

MOBILE: 0907-047-2321

CONTACT PERSON: MS. JENNYLYN BOADILLA

ALBAY

JO-ADEL ELECTRONICS REPAIR SHOP PI-02 SAINT ANTHONY ST., SAN JUAN, TABACO CITY, ALBAY

MOBILE: 0928-602-7736 CONTACT PERSON: ADELUZ ASUR

ILOILO

NACES APPLIANCE CORPORATION NACES BLDG, #10 DELGADO ST, ILOILO CITY

TEL: (033) 337-7696 / (033-508-2205 MOBILE: 0909-701-0202 CONTACT PERSON: MS. LORELIE LIM

BACOLOD

WESTERN ELECTRONICS DOOR 9-12 MIGANT CENTER COR. BURGOS LOCSIN ST., BACOLOD CITY

TEL: (034) 434-9408 MOBILE: 0933-864-1976 / 0932-696-3663 CONTACT PERSON: MR. SHERWIN
DAMASCO/SHILEA LU

CALBAYOG

JOVAN APPLIANCE SERVICE CENTER BRGY. OBRERO, CALBAYOG CITY

MOBILE: 0917-627-4802/ 0906-474-6426 CONTACT PERSON: ELSA BURATO

CEBU

MANSWELL REFRIGERATION AND AIRCONDITIONING SERVICES #85 SIKATUNA ST, CEBU CITY

TEL: (032) 253-0752 MOBILE: 0929-746-1236 / 0943-641-5319

CONTACT PERSON: MR. JULIUS SUICO/QUANDELYN SUICO

BIO PLUS ELEC. REPAIR CENTER C. PADILLA ST, SAN ROQUE, MAMBALING, CEBU CITY

TEL: (032) 262-1339 MOBILE: 0922-474-4991 CONTACT PERSON: MS. ZYSELDA MABUTE

TACLOBAN

TACLOBAN CHRONICLES ELECTRONICS SERVICE CENTER

BRGY. 76, REAL ST., FATIMA VILLAGE, TACLOBAN CITY

MOBILE: 0917-118-1456 / 0921-992-4220 CONTACT PERSON: MS. BELLE

DAVAO

TECHSOLUTION ELECTRONICS SERVICE CENTER DOOR 2 LEONOR BLDG., QUIRINO AVE.,
COR. SAN PEDRO EXT. DAVAO CITY

TEL: (082)-8222-6498 MOBILE: 0932-121-6577 CONTACT PERSON: MS. IVY/STEVE/HELVIN

ZAMBOANGA

N & N SERVICE CENTER SUNRISER LANE 1, TALON TALON LOOP, ZAMBOANGA CITY

MOBILE: 0995-918-1624 / 0920-962-3673 CONTACT PERSON: MS. NENENG CHION ACEBRON